


CABINET PARTS

For Models: LEQ8858HQ0, LEQ8858HZ0 (Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	17	279318	Terminal, Tinned	37		Handle, Door
	LIT3397618	Instructions,	''		& Brass (3)		690270	
		Installation			(Includes Illus. 39)		690271	Almond
	LIT3406080	Use & Care Guide	18		Cabinet	38	3406129	
	LIT3977704	Label, Wiring	'		(Includes Illus.	••		Assembly
		Diagram			Nos. 5,7,15,41	39	279393	
2	343641	Screw, 10-16 x 1/2			And 57.)			Kit (For
3		Screw, 8-18 x 3/8		3399585	White			Terminal Block)
4		Bumper		3399586	Almond	40	697776	Screw, 10-32 x 5/8
5	3396795	Cover, Block	19	98234	Clip, Ground	41		Block, Terminal
6	342043	Screw, 10-32 x 3/8	20		Lock, Front Top (2)	51		Hinge, Top (2)
7		Panel, Rear	21		Panel, Front	53	691366	
10		Door Switch		695620				Assembly
		Assembly		695621	Almond	56	660996	Belt, Drive
11	697773	Screw, 6-20 x 7/8	23	685203	Clip, Felt Pad (3)	57	348780	Base, Motor
13	3357011	Screw, 10-16 x 1/2	24	3389441	Catch, Door	58	3400500	
14	692495	Spring, Door (2)			Assembly			5/16-18 x 3/4
15	3394083	Clip, Front	26	337189	Clip, Hinge (2)	59	3394341	Pulley, 60 Hz.
		Panel (2)	27	694091	Screw, 8-18 x 3/8	62	3976707	Motor Assembly
16	3392100	Foot, Dryer	28	8066056	Hinge, R.H.			60 Hz.
	279810	Foot-Optional		8066057	Hinge, L.H.	63	660658	Clamp, Motor
		(Extended Length	33	696144	Strike, Door	64	3404162	Clamp, Motor
		Package of 2)	35	695737	Door, Rear			(W/Shield)
		(Not Included)	36		Door, Front	67	3390731	
				3393549	White	87	3393008	Screw, 10-16 x 1/2
				3393550	Almond			

TOP AND CONSOLE PARTS

For Models: LEQ8858HQ0, LEQ8858HZ0 (Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LEQ8858HQ0, LEQ8858HZ0 (Designer White) (Designer Almond)

	Dant			Do-=4	,	, 111	D	
Illus.	Part	DECCRIPTION	Illus.	Part	DECCRIPTION	Illus.	Part	DECCRIPTION
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3397545	Panel, Rear	13	688983	Screw, 8-18 x 5/8	31	8283128	Harness, Wiring
		Console	14	3400859	Screw, Grounding	32	3977410	Wire, Jumper
2	3401684	Wire, Jumper	15	3395683	Connector			(Temperature)
		(Black)			(Motor)	33	3397269	
3	693995	Screw, Hex Head	16		Top			(Timer)
4		Cap, End (L.H.)		3396022	White	34	3347243	
	3358528			3396023	Almond			6-Circuit
	3358529		17		Knob, Control	35	94614	Terminal
5	3405156	Switch,		3950759	White	39	3398095	
		Finish Guard		3950760	Almond			Push-To-Start
6	388326	Screw, Console	18	3394427	Clip-Harness	48		Timer Knob
7	694419		19	3401671				Assembly
8		Cap, End (R.H.)			(White)		3406143	
	3358513		20	3401144	Connector,		3406144	Almond
	3358514	Almond			(PTS Relay)	50	3936144	Connector
9	3399640	Switch,	21	3976570		51	3977407	Control,
		Temperature	22	3397695	Wire, Jumper			Electronic
10	349639				(Guard On/Off)	52	3391885	Connector, Edge
11		Cover, Lint	23	8283127	Resistor Assembly	53	8054298	Bracket, Control
		Screen	29	3390646	Screw, Mounting	54		Panel, Control
	688150	White			(8-18 x 5/16)		3976770	
	689310	Almond	30	357213	Nut, Push-In (2)		3976771	Almond
12	339229	Hinge, R.H.				55	343641	Screw, 10-16 x 1/2
		Hinge, L.H.						,
		•						

OPTIONAL PARTS (NOT INCLUDED)

Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White 72107 Almond

PAINT, PRESSURIZED SPRAY

(13 oz.)

350930 White 350956 Almond 350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut) 978883 Almond (Uncut)


Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

LIT677818 Dryer

BULKHEAD PARTS

For Models: LEQ8858HQ0, LEQ8858HZ0 (Designer White) (Designer Almond)



BULKHEAD PARTS

For Models: LEQ8858HQ0, LEQ8858HZ0 (Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute	13	343641	Screw, 10-16 x 1/2	32	348860	Electrode, Outside
		Assembly	14	3397566	Box, Heater	33	3406124	Bulb
2	487909	•	15	3399693	Thermostat,	34	3402841	Lens, Drum Light
3	3388703	Washer-Support			250°F	41		Ring, Tri
4		Seal, Lint			(121.1°C)	42		Shaft, L.H.
•		Chute	16	3404232	Bracket, Drum	43	3399507	Shaft, R.H.
5	90767				Light	44		Roller, Support
6		Shield, Exhaust	17	3403585	Element, Heater	46		Washer, Support
7		Thermal Fuse	18	3977358		47		Nut, 3/8-16
8	3977425	Thermostat,			Plug	48	3403414	Bulkhead
_		Internal-Bias	19	279457	Wire Kit, Terminal	49	3403634	Socket Assembly
9	3399848	Thermal, Cut-Off			(For Heater	62		Ring, Bearing (2)
•		(Hi-Limit			Element Wiring	63		Screw, 11-16 x 3/4
		Thermostat Illus.			Harness Repair)	66		Seal, Rear Drum
		No.15 Included)	20	489463	- · · · · · · ·	67		Drum Assembly
10	694089	Wheel, Blower	22	3394196	Seal, Blower	68	692490	Baffle, Drum (2)
-		(Includes Illus.	28	3394231	Clip, Sensor	69		Bracket, Support
		No. 22)	29	298877	• •	70	90296	
11	3405016		30	348861		71		Baffle, Drum (1)
12	3398161		31	348859	•	73	339956	